


# Fixing Instruction for Plate & Dish Holder

## 1. Accessories:




## 2. Specification & Cabinet Width:


| Specification | Cabinet Width |
|---------------|---------------|
| DxWxH (mm)    | W (mm)        |
| 280x565x65    | 600           |
| 280x665x65    | 700           |
| 280x765x65    | 800           |
| 280x865x65    | 900           |
| 280x965x65    | 1000          |
| 280x465x65    | 500           |
| 280x365x65    | 400           |
| 280x415x65    | 450           |
| 280x515x65    | 550           |
| 280x615x65    | 650           |
| 280x715x65    | 750           |
| 280x815x65    | 850           |
| 280x915x65    | 950           |

## 3. Fixing Step:

- (1) Choose a suitable cabinet according to the specification of particular products (please refer to drawing 1):



- (2) Drill the side-board of the cabinet then fix accessory "A" & "B" one by one as the following drawings.



## (3) Remarks:

- a. Size "A" & Size "B" are based on high of cabinet. The following sizes are for your reference:

A=275mm, B=300mm (Both sizes for reference only)

- b. Depth of 4-  $\phi 10$  hold is 7~9mm, please be careful that the side-board of cabinet can not to be drilled through.